USER MANUAL

VELA Samba™ 410

WWW.VELA.EU

CONTENTS

1.0. INTRODUCTION 3

1.1. SAFETY 4

1.2. WARRENTY 4

1.3. UNPACKING THE CHAIR 4

1.4. MAINTENANCE VELA SAMBA 4

1.5. GENERAL INSTRUCTIONS 5
1.5.1. Transportation 5
1.5.2. Stability and balance 5

1.6. VELA SAMBA USERMANUAL 6

1.7. TECHNICAL DATA 7

1.0. INTRODUCTION

Dear customer,
Thank you for choosing VELA Samba, which is certain to give you years of enjoyable use. The user manual contains useful information on set-up, operation, maintenance, technical data etc.

This user manual describes VELA Samba 410.

Important
Please read this manual carefully and keep it for future reference. It must always be readily available to the user. This user manual must always be kept with the chair.

The manual is also available on VELA's website: www.vela.eu. If you have any questions, please contact VELA.

The chair is made by VELA, Vermund Larsen A/S, Goeteborgvej 12, 9200 Aalborg SV, Denmark. .

1.1. SAFETY

This chair carries the CE mark and complies with all current EU regulations.Remove the CE-mark, when rebuilding the product or when using other than original VELA spare parts and fittings.

RECYCLING

Many of the materials used in the chair's construction can be recycled. Deliver the chair to VELA or our local recycling centre.

DISTRIBUTOR:

1.2. WARRANTY

VELA offers a 1-year warranty against defects in workmanship and materials. The warranty applies only if original spare parts and accessories are used, and always provided that adjustments are carried out by authorised service technicians. The warranty does not cover accidental damage, including damage caused by misuse or neglect. The warranty does not extend to non-durable parts, which are subject to normal wear and tear and need periodic replacement.
VELA assumes no liability for damage to the product or injury to the user as a result of:

- Transport
- Misuse
- Ordinary wear and tear
- Incorrect use
- Using non-original spare parts and accessories
- Adjustments carried out by unauthorised service technicians

VELA reserves the right to inspect the product being claimed for and the relevant documentation before agreeing to the warranty claim, and to decide upon whether to replace or repair the defective product. It is the customer's responsibility to return the item being claimed for under warranty to the address of purchase. The warranty is given by VELA or, subsequently, an VELA dealer.

REPAIR

If there is a fault on your chair you should contact your dealer at once. Defective chairs should not be used. If your chair needs reconditioning or repair, only original VELA parts must be used.

Accessories or available spare parts which are broken can be forwarded to VELA for repair. If fault in the fundamental parts, the whole chair need to be returned to VELA for repair. VELA will not be held responsible for damage or injury caused by use of non-original parts or repairs made by a non-authorized VELA person.

1.3. UNPACKING THE CHAIR

VELA Samba is supplied in cardboard packaging which is developed and produced to ensure the least possible impact on the environment and with focus on ease of use. In case of defects or transport damage to the chair, please contact VELA immediately. You must not try to repair any damage yourself or start using the chair.

The box in which the chair was supplied should contain:

- VELA Samba
- This user manual

1.4. MAINTENANCE OF VELA SAMBA

We recommend that you have your VELA Samba serviced once a year to identify any defective or worn parts. The gasspring functions without any maintenance. Do not expose the gasspring to pressure, high temperatures or perforation.

THE CHAIR IS NOT ASSEMBLED, TO ASSEMBLE THE CHAIR:

1. Put the gas spring down the gap in the frame.
2. Take the seat support and the cusion and put in on the gas spring.

IMPORTANT: The gas spring shall be pushed down gently, but hard enough to ensure that it is locked.

Wheels
Wheels should be regularly checked and cleaned of any fluff etc.

Base
Wash regularly with a mild solution of lukewarm water and pH-neutral washing-up liquid.

Upholstery
The fabric is made of polyester, which only needs to be vacuumed occasionally and wiped with a cloth rinsed in clean water and tightly wrung. Make sure to remove any stains as quickly as possible. Always use a moist clean, white cotton cloth. For more stubborn stains, use a bit of mild washing-up liquid. Do not use any cleaning materials containing chlorine or methylated spirit. Any incontinence cover should be machine-washed on a gentle cycle.

1.5. GENERAL INSTRUCTIONS

To ensure correct use of the VELA Samba, please note the following:

1.5.1. TRANSPORTATION

Always remember to lock the chair in position when transporting VELA Samba. No one should sit in the chair while it is being transported.
Temperature during transport: -104 degrees to +158 degrees
Humidity: 15%-95%
Air pressure: ppp up to 0.6 miles above sea level

1.5.2. STABILITY AND BALANCE

VELA Samba is designed to be used on a daily basis at work or in the home. It is intended for seated work.

1.6. USERMANUAL VELA SAMBA 410

It is important to keep you back and loin in motion - also when you are sitting. Use the VELA Samba 410 regularly.
Find a seating position where you are comfortable with both legs slightly separated and the feet placed on the floor.

Rotate the upper torso in different directions and tilt from side to side. An exaggerated tilting movement will give you a good stretching of the muscles, but be mindful of how much you can handle.

◀ 1.5.1. HEIGHT ADJUSTMENT

The height of the VELA Samba 410 can be adjusted using the gas springs. This is done by pulling on the small lever.

Replacement of the gas spring: Only by the service support team from your dealer or a skilled technical person.

◀ 1.5.2. REMOVABLE CUSION

The cushion is fitted to the chair with strong Velcro and can therefore easily be removed from the chair and be used on other chairs or in your car - wherever you are.

You should not sit on the seat support withou the cusion.

1.7. TECHNICAL INFORMATION

CONSTRUCTION:

- Shaped steel frame made from profile tubing ensures that all the wheels remain in contact with the floor, even on slightly uneven surfaces
- Each wheel is secured with a wheel spindle in a tower
- Outer tubing in lacquered aluminium
- Height adjustment with gas springs
- Seat mechanism is mechanical

	VELA Samba 410
Seat size	18,5 x 14,1 inches
Sitting height	16,5-22,4 19,2-27,1 23,6-33,8
Frame diameter	19,7
Max. load	209 lbs.
Weight	11 lbs.

VELA · Goeteborgvej 12 · DK-9200 Aalborg SV · Denmark · mail@vela.dk · www.vela.eu

VELA Samba 410 USA 1-2011